

## Installation manual for ZLA-MFD

### **Connect an external audio and video source with the following navigations systems:**

Audi Navi Plus RNS-D (4:3) oder MFD, MFD2, RNS2, RNS510.

Audi TV Tuner:

4DO 919 146 B

4DO 919 146 C

VW TV Tuner:

3B0 919 146

### Installation:

1. Remove and disconnect the 54 pin connector from the TV tuner.
2. Pull out the insertion from the connectors housing.
3. Slide the blue plate from ZLA-MFD1 besides the others.
4. Move back the insertions in the connectors housing.
5. Plug the connector into the TV tuner.

### Connector assignment:

Connection 1 and 2: TV antennas

Connection 3: 54 pin connector for navigation system  
Pin 40 to 46 – AUX1, Pin 47 to 53 – AUX2

The blue RCA jacks from ZLA-MFD1 can respectively used for video CVBS input. The low level audio signal can be connected with the red RCA jacks (right channel) and the black RCA jacks (left channel). Inputs AUX1 and AUX2 can be switched within the menu from the navigation system. To get further instructions for use or switching the AUX input, please refer to the navigation-manual.

**Note:** On VW Phaeton and Bentley with ZAB navigation only one AV-input works!

### Rear Side TV Tuner:

